

*This Space for Architect/Engineer Approval*

Job Name \_\_\_\_\_ Date \_\_\_\_\_

Model Specified \_\_\_\_\_ Quantity \_\_\_\_\_

Customer/Wholesaler \_\_\_\_\_

Contractor \_\_\_\_\_

Architect \_\_\_\_\_

**TO THE INSTALLER**  
THIS SPOUT CAN BE USED AS A RIGID OR SWIVEL SPOUT

1. IF SPOUT NUT IS NOT ASSEMBLED TO SPOUT, REMOVE OUTLET AND ASSEMBLE SPOUT NUT OVER OUTLET END, THEN RUN SPOUT NUT DOWN UNTIL IT SITS ON SHOULDER OF SPOUT JOINT. REASSEMBLE OUTLET.
2. FOR RIGID SPOUTS: PLACE 1/8" BLACK THICK PLASTIC WASHER (075-015097-45) INTO SPOUT BASE OF FAUCET AND DISCARD BOTH WHITE PLASTIC SPLIT WASHERS (064-015096-45).
3. FOR SWIVEL SPOUTS: ASSEMBLE BOTH WHITE PLASTIC SPLIT WASHERS (064-015096-45) TO SPOUT JOINT AND DISCARD 1/8" BLACK THICK PLASTIC WASHER (075-015097-45).
4. ASSEMBLE SPOUT ASSEMBLY INTO SPOUT BASE OF FAUCET AND TIGHTEN SPOUT NUT.

|                            |                   |              |              |                |                 |
|----------------------------|-------------------|--------------|--------------|----------------|-----------------|
| Model Number<br>Q016062-45 | Date<br>3/10/2006 | Scale<br>1:1 | Drawn<br>DHL | Checked<br>JRM | Approved<br>JHB |
|----------------------------|-------------------|--------------|--------------|----------------|-----------------|

Product Specifications:

**Swivel / Rigid Gooseneck Kit**



T&S BRASS AND BRONZE WORKS, INC.  
2 Saddleback Cove, P.O. Box 1088  
Travelers Rest, South Carolina 29690  
Phone: 800.476.4103 Fax: 800.834.3518, Simi Valley 800.423.0750



REG. #A2601  
ISO #9001