

Last As Long As The Building

## "Y" Valve Assembly Instructions 560-045KJK & 560-145KJK

Assemble the "Y" valve to the nipple supplied, then connect the "Y" valve to the solenoid assembly inlet.

Use Teflon tape on all threads to ensure a leak-free joint.

## **A** CAUTION

Do not use plumbers putty, silicone sealant or pipe dope on threads. The solenoid could become contaminated and will void any warranty.

