


B-0107-C



Low-Flow Spray Valve Assembly

1	Screw, Handle	003199-45
2	Nut, Handle	003198-45
3	Handle	001120-45
4	Shield, B-0107-C Only	002659-45
5	Asm, Nozzle	002662-40
6	Washer	010476-45
7	Ring, Hold Down	000907-45
8	Asm, Bonnet	002856-40

