


B-0113, B-0113-B, B-0113-C



Model B-0113-B includes wall bracket (B-0109-01)
 Model B-0113-C includes Low Flow Spray Valve (B-0107-C) See page 13 for part explosion

Pre-Rinse Assembly

1	Faucet Body	*
2	Asm, Spindle - Hot	005960-40
3	Asm, Spindle - Cold	005959-40
4	Handle, Lever - Blank	001638-45
5	Screw, Handle	000922-45
6	Index, Button - Hot (Red)	001661-45
7	Index, Button - Cold (Blue)	001660-45
8	Washer, Body	*
9	Locknut, Shank	000965-45
10	Lock Washer, EZ-Inst all	*
11	Nipple, 3/8" x 24"	000372-40
12	Swivel Nut	*
13	Swivel Piece	*
14	O-Ring, Swivel Piece	001074-45
15	Asm, Finger Hook & Screw	002873-40
16	Spring, Body	000821-40
17	Spring, Overhead	000888-45
18	Asm, Flex Stainless Steel Hose	B-0044-H
19	Asm, Spray Valve	B-0107
20	Washer	010476-45
41	Flexible Connector Hoses	*

