

Sill Faucet Assembly

1	Asm, Spindle	005990-40
2	Cap, Key Stop	001605-45
3	Flo Preventer	B-0972
4	T' Hande, Key Stop	001802-45
5	Screw, Key Stop Handle	002432-45

