


B-1100-XS



Base Faucet Assembly

1	Screw, Lever Handle	000922-45
2	Index, Button, Blue/Cold	001660-45
	Index, Button, Red/Hot	001661-45
3	Handle, Lever	001638-45
4	Asm, Spindle NSF - RH/Cold	009753-25
	Asm, Spindle NSF - LH/Hot	009754-25
5	Seat	000763-20
6	Locknut, Cover Plate	000712-25
7	Escutcheon, Body	001258-40
8	Washer	000999-45
9	Locknut	002954-45
10	Asm, Swing Nozzle, 6"	059X
11	Washer, Swivel	009538-45
12	Sleeve, Swivel	011429-45
13	O-Ring, Swivel	001074-45

