


B-0508



Single Pedal Valve

1	Screw, Wall Mount	003749-45
2	Asm, Bonnett	005312-40
3	Spring, Cold Pedal	000887-45
4	Bushing	001602-45
5	Ring, 'E'-Style	012512-45
6	Pad, Single Pedal	012515-20
7	Screw, Nylon	000917-45
8	Locknut, Adjustable	000952-45
9	Set Screw, Nylon	001123-45

