


B-0576



Range Faucet Assembly

1	Piece, Swivel	001622-25
2	O-Ring, .103 C/S x .206 I.D.	009268-45
3	Dynamic Bearing	001621-20
4	Spring, O-Ring Bearing	001625-45
5	Nut, Swivel	001623-45
6	O-Ring, Center Body	001069-45
7	O-Ring, .070 C/S x .364 I.D.	009267-45
8	Nozzle	001626-40
9	Adapter, 1/8" Female x Aerator Male	001624-25
10	Aerator	B-0199-01

