


B-0720, B-0720-RGH



Model B-0720 has a polished chrome plated finish. Model B-0720-RGH has a rough chrome plated finish

Sill Faucet Assembly


1	Spout	001618-40
2	Cap, Key Stop	001605-45
3	Asm, Vacuum Breaker	B-0969
4	Nipple	002534-25
5	T' Handle for Supply Stop	001802-45
6	Screw, Supply Stop	002432-45





B-0730, B-0730-POL

Model B-0730 has a rough chrome plated finish. Model B-0730-POL has a polished chrome plated finish




Sill Faucet Body

- | | | |
|---|-------------------------|-----------|
| 1 | Asm, Spindle | 005990-40 |
| 2 | Cap, Key Stop | 001605-45 |
| 3 | T' Handle, Supply Stop | 001802-45 |
| 4 | Screw, Loose Key Handle | 002432-45 |



B-0731, B-0731-POL




Sill Faucet Assembly

1	Asm, Spindle	005990-40
2	Cap, Key Stop	001605-45
3	T' Hande, Key Stop	001802-45
4	Screw, Key Stop Handle	002432-45



B-0736, B-0736-POL

Model B-0736 has a rough chrome plated finish. Model B-0736-POL has a polished chrome plated finish




Sill Faucet Assembly

1	Asm, Spindle	005990-40
2	Cap, Key Stop	001605-45
3	Flo Preventer	B-0972
4	T' Handle, Supply Stop	001802-45
5	Screw, Key Handle	002432-45




B-0737, B-0737-POL



Sill Faucet Assembly

1	Asm, Spindle	005990-40
2	Cap, Key Stop	001605-45
3	Flo Preventer	B-0972
4	T' Handle, Key Stop	001802-45
5	Screw, Key Stop Handle	002432-45

B-0805




Slow Self-Closing Faucet Assembly

- | | | |
|---|--|-----------|
| 1 | Asm, Slow Self-Closing, Meter Valve, Bla | 002874-40 |
| 2 | Aerator | B-0199-02 |
| 3 | Washer | 000999-45 |
| 4 | Locknut | 002954-45 |
| 5 | Nut, Coupling | 000958-20 |




B-0805-VR



Faucet Assembly

- | | | |
|---|--|-----------|
| 1 | Asm, Self-Closing, Meter Valve, Blank002874-40 | |
| 2 | Aerator | B-0199-02 |
| 3 | Locknut | 002954-45 |
| 4 | Washer | 000999-45 |
| 5 | Nut, Coupling | 000958-20 |

B-0806




Slow Self-Closing Faucet Assembly

- | | | |
|---|---|-----------|
| 1 | Asm, Self-Closing, Meter Valve, Blank 002874-40 | |
| 2 | Asm, Spray Head | B-0103 |
| 3 | Washer | 000999-45 |
| 4 | Locknut | 002954-45 |
| 5 | Nut, Coupling | 000958-20 |



B-0807




Self-Closing Faucet Assembly

- | | | |
|---|-------------------------------------|-----------|
| 1 | Asm, Self-Closing, Meter Valve, Bla | 002874-40 |
| 2 | Aerator | B-0199-01 |
| 3 | Washer | 000999-45 |
| 4 | Locknut | 002954-45 |
| 5 | Tailpiece | 001592-20 |
| 6 | Nut | 000958-20 |
| 7 | Spreader Unit | 002899-40 |



B-0830




Slow Self Closing Faucet Assembly

- | | | |
|---|---|-----------|
| 1 | Asm, Slow Self-Closing, Meter Valve - H 002879-40 | |
| | Asm, Slow Self-Closing, Meter Valve - C 002880-40 | |
| 2 | Washer, Rosette | 001000-45 |
| 3 | Locknut | 000958-20 |
| 4 | Nut, Coupling | 002954-45 |
| 5 | Aerator | B-0199-03 |



B-0831




Slow Self Closing Faucet Assembly

- | | | |
|---|---|-----------|
| 1 | Asm, Self Slow-Closing, Meter Valve - H 002879-40 | |
| | Asm, Self Slow-Closing, Meter Valve - C 002880-40 | |
| 2 | Aerator | B-0199-03 |
| 3 | Washer, Rosette | 001000-45 |
| 4 | Locknut | 000958-20 |
| 5 | Nut, Coupling | 002954-45 |



B-0831-01




Slow Self Closing Faucet Assembly

1	Screw, Handle	000925-45
2	Index, Snap-In, Blue/Cold	001686-45
	Index, Snap-In, Red/Hot	001194-45
3	Handle, Wrist Action, 4"	000078-40
4	Asm, Meter Cartridge, Wrist Action	012449-40
5	Washer, Rosette	001000-45
6	Locknut	002954-45
7	Nut, Coupling	000958-20
8	Aerator	B-0199-03



B-0833, B-0834




Slow Self Closing Faucet Assembly

1	Gooseneck	000393-40
2	Aerator	B-0199-02
3	Asm, Self-Closing, Meter Valve - Hot	002879-40
	Asm, Self-Closing, Meter Valve - Cold	002880-40
4	Washer, Rosette	001000-45
5	Locknut	002954-45
6	Nut, Coupling	000958-20
7	Asm, Popup Drain (B-0833)	B-0898





B-0840, B-0841




Model B-0840 includes aerator outlet (B-0199-02). Model B-0841 includes rosespray outlet (B-0103).

Basin Faucet Assembly

1	Washer	000999-45
2	Locknut	002954-45
3	Nut, Coupling	000958-20
4	Aerator (B-0840)	B-0199-02
5	Asm, Rosespray (B-0841)	B-0103
6	Asm, Spindle Eterna - Hot	005960-40
7	Handle, Alpine Lexan, Clear	001144-45
8	Index, Button, Cold	001327-40
9	Screw, Handle	000925-45




B-0842



Basin Faucet Assembly with Spreader Unit


- | | | |
|----|----------------------------------|-----------|
| 1 | Screw, Handle | 000925-45 |
| 2 | Index, Snap-In, Dark Blue | 001196-45 |
| 3 | Handle, Wrist Action, 4" | 000078-45 |
| 4 | Asm, Spindle Eterna BWH | 006010-40 |
| 5 | Aerator | B-0199-02 |
| 6 | Washer | 000999-45 |
| 7 | Locknut | 002954-45 |
| 8 | Nut, Coupling | 000958-20 |
| 9 | Tailpiece | 001592-20 |
| 10 | Asm, Spreader Unit | 002899-40 |
| 11 | Adapter, 1/2" Female x 1/2" Male | 010321-45 |





B-0865, B-0865-04

Model B-0865-04 includes 4" Wrist Action handles (B-WH4). Model B-0865 includes 6" Wrist Action handles (B-WH6).



Commercial Faucet Assembly

1	Screw, Handle	000925-45	12	Washer	000981-45
2	Index, Snap-In, Blue/Cold	001686-45	13	Nut, Coupling	000958-20
	Index, Snap-In, Red/Hot	001194-45	14	Nipple	000342-20
3	Handle, Wrist Action, 6" (B-0865)	B-WH6	15	Locknut	002954-45
	Handle, Wrist Action, 4" (B-0865-04)	B-WH4	16	O-Ring, Knuckle Joint	001060-45
4	Escutcheon	001257-40	17	Locknut, Yoke	000956-45
5	Asm, Side Body - Cold	161A	18	Center Body	000136-40
	Asm, Side Body - Hot	162A	19	Washer	000999-45
6	Asm, Spindle, Eterna - RH/Cold	006478-40	20	Washer, Swivel Yoke, Top	000994-45
	Asm, Spindle, Eterna - LH/Hot	006477-40	21	O-Ring, Swivel Yoke, Center	001068-45
7	Locknut, Body Top	000959-20	22	Washer, Swivel Yoke, Bottom	000993-45
8	Washer, Body	002290-45	23	Washer, Yoke Star	000982-45
9	Washer, Nipple	001006-45	24	Asm, Nozzle Gooseneck	120X
10	Locknut, Body Bottom	000960-20	25	Asm, Spray Head, Rosespray	B-0103
11	Washer, Beveled	001091-45			

