


B-1100, B-1100-LN



Model B-1100-LN does not include nozzle assembly (002877-40)



Faucet Assembly

- | | | |
|----|--------------------------------|-----------|
| 1 | Screw, Lever Handle | 000922-45 |
| 2 | Index, Button, Blue/Cold | 001660-45 |
| | Index, Button, Red/Hot | 001661-45 |
| 3 | Handle, Lever | 001638-45 |
| 4 | Asm, Spindle NSF, RH/Cold | 009753-25 |
| | Asm, Spindle NSF, LH/Hot | 009754-25 |
| 5 | Seat | 000763-20 |
| 6 | Locknut, Cover Plate | 000712-25 |
| 7 | Escutcheon, Body | 001258-40 |
| 8 | Washer | 000999-45 |
| 9 | Locknut | 002954-45 |
| 10 | Asm, Swing Nozzle, 6" (B-1100) | 059X |
| 11 | Washer | 009538-45 |
| 12 | Sleeve | 011429-45 |
| 13 | O-Ring | 001074-45 |

