




B-1120, B-1120-LN, B-1121, B-1122, B-1123

Model B-1120-LN does not include nozzle assembly (059X). Model B-1121 includes a 8" nozzle (060X). Model B-1122 includes a 10" nozzle (061X). Model B-1123 includes a 12" nozzle (062X).



Faucet Assembly

1	Screw, Lever Handle	000922-45	8	Washer	000999-45
2	Index, Button, Blue/Cold	001660-45	9	Locknut	002954-45
	Index, Button, Red/Hot	001661-45	10	Asm, Swing Nozzle, 6" (B-1120)	059X
3	Handle, Lever	001638-45		Asm, Swing Nozzle, 8" (B-1121)	060X
4	Asm, Spindle NSF - RH/Cold	009753-25		Asm, Swing Nozzle, 10" (B-1122)	061X
	Asm, Spindle NSF - LH/Hot	009754-25		Asm, Swing Nozzle, 12" (B-1123)	062X
5	Seat	000763-20	11	Washer	009538-45
6	Locknut, Cover Plate	000712-25	12	Sleeve	011429-45
7	Escutcheon, Body	001259-40	13	O-Ring	001074-45

