


B-1410




Quick Connect Spray Hose Assembly

- | | | |
|---|-----------------------------------|-----------|
| 1 | Asm, Spray, Quick Connect | B-1421 |
| 2 | Asm, Spray Valve, Quick Connect | B-1420 |
| 3 | Asm, Hose, Stainless Steel, 44" | B-0044-H |
| 4 | Washer | 010476-45 |
| 5 | Adapter, 1/2" Male x 3/4"-14 Male | 000547-25 |





B-1420




Valve with Quick Connection Socket

1	Screw, Handle	003199-45
2	Nut, Handle	003198-45
3	Handle, Squeeze Valve	001120-45
4	Asm, Bonnet	002856-40



B-1421




Quick Connect Spray

1	Screw, Spray Face	000913-45
2	Spray Face	001121-45
3	Spray Head	007861-45
4	Cup, Spray	000019-40



B-1550-C




See page 11 for exploded view
of spray valve (B-0107)

Hose Reel with Spray Valve

- | | | |
|---|------------------|-----------|
| 1 | Asm, Spray Valve | B-0107 |
| 2 | Asm, Handle | 002881-40 |





B-1716-02



Spray Wash Faucet with Vacuum Breaker

1	Asm, Spray Valve	002857-40
2	Cap	000622-40
3	Spring	000894-45
4	O-Ring, Spindle	001063-45
5	Washer, Bonnet	000974-45
6	Stem	000826-20
7	O-Ring, Insert	001062-45
8	Cap, Hex	000623-40
9	Adapter, 3/8" Male x 3/4"-14 Male	000545-25
10	Asm, Angled Stop	006998-40
11	Screw, Handle	000922-45
12	Index, Button, Blue/Cold	001660-45
13	Handle, Kitchen, 4-Arm	002521-45
14	Asm, Spindle, Eterna - Hot	005960-40
15	Flange	000014-40
16	Finger Hook	002309-40
17	Screw, Wall Mount	000915-45

B-1912-07




Double Joint Front Nozzle

- | | | |
|---|----------------|-----------|
| 1 | O-Ring, Swivel | 001074-45 |
| 2 | Sleeve, Swivel | 011429-45 |
| 3 | Washer, Swivel | 009538-45 |



B-1912-09




Nozzle Assembly

- | | | |
|---|----------------|-----------|
| 1 | Washer, Swivel | 009538-45 |
| 2 | Sleeve | 011429-45 |
| 3 | O-Ring | 001074-45 |



B-1912-10




Straight Swivel Extension

- 1 Nipple, 3/8" X 6" 000362-40
- 2 Swivel Body 000585-25



B-1912-14




Swing Nozzle, 12"


1	Washer, Swivel	009538-45
2	Sleeve	011429-45
3	O-Ring, Nozzle	001074-45



B-1929




B-2045



Glass Pitcher Filler

1	Hexcap	000623-40
2	O-Ring	001062-45
3	Tip, Glass Filler	003090-45
4	Screw, Handle	003199-45
5	Nut, Handle	003198-45
6	Lever Arm, Blue Lexan	001145-45
7	Pushbutton	000752-45
8	Nut, Volume Control	000714-25
9	Stem, Volume Control	000834-25
10	Washer, Bonnet	000974-45
11	Packing Stem	001100-45
12	Spring	000894-45
13	Washer, Pedestal	001003-45
14	Locknut, Pedestal	002954-45

B-2076




Nozzle Assembly

1 O-Ring, Nozzle

001074-45




B-2098




B-2180

Pre-Rinse with Add-On Faucet


1	Asm, Base Faucet	002832-40
2	Asm, Coupling Flange	002893-40
3	Handle, Lever	001638-45
4	Index, Button, Blue/Cold	001660-45
	Index, Button, Red/Hot	001661-45
5	Screw, Handle	000922-45
6	Asm, Spindle Eterna - Cold	002711-40
	Asm, Spindle Eterna - Hot	002712-40
7	Asm, Add-On Faucet	B-0155-LN
8	Handle, Lever	001638-45
9	Screw, Handle	000922-45
10	Asm, Spindle, Quarter Turn	007947-40
11	Nipple, 3/8" x 3"	000358-40
12	Asm, Swing Nozzle, 18"	065X
13	Washer	009538-45
14	Sleeve	011429-45
15	O-Ring	001074-45
16	Nipple, 3/8" x 18"	000369-40
17	Screw, Finger Hook	000916-45
18	Finger Hook	000021-40
19	Spring, Body	000821-40
20	Spring, Overhead	000888-45
21	Asm, Spray Valve	B-0107




B-2183



B-2250, B-2250-B



Model B-2250-B includes wall mounting bracket (B-0109-01)



Pre-Rinse Unit

1	Spring, Overhead	000888-45
2	Spring, Body	000821-45
3	Finger Hook	000021-40
4	Screw, Finger Hook	000916-45
5	Nipple, 3/8" x 24"	000372-40
6	Asm, Bracket, Wall Mount, 6" (B-2250-BB-0109-01)	
7	Nipple	000346-40
8	Set Screw	001584-45
9	Screw, Wall Mount	000915-45
10	Asm, Hose, Stainless Steel, 44"	B-0044-H
11	Asm, Spray Valve	B-0107

