








BL-4705-03



Fume Hood Valve Assembly

- | | | |
|---|--------------------|-----------|
| 1 | Screw, Handle | 000922-45 |
| 2 | Handle, Stem Valve | 001149-20 |
| 3 | Seat | 000529-20 |
| 4 | Asm, Spindle | 005985-40 |
| 5 | Locknut, Body Top | 000959-40 |

